

Worldwide Soaring Turnpoint Exchange

Unofficial Coordinates for the Podhorany, Czech Republic Control Points

Contest: PMCRd Podhorany, 2004

Courtesy of Richard Santus (info@letistepodhorany.cz)

Time zone: MET, summer offset from GMT is 2:00 and in winter it is 1:00.

Aeroklub Pardubice

Printed Monday, 29 March 2004 at 02:49 GMT

UNOFFICIAL, USE AT YOUR OWN RISK

Always consult the relevant publications for current and correct information.

This service is provided free of charge with no warranties, expressed or implied.

User assumes all risk of use.

Number	Name	Latitude ° , ' , ''	Longitude ° , ' , ''	Latitude ° , ' , ''	Longitude ° , ' , ''	Elevation Meters	Codes*	Description	Distance Km	Bearing
1	As	50 13 08 N	12 10 59 E	50 13.133 N	12 10.983 E	600	T	Nádrží	242	279
2	Baska	49 38 34 N	18 21 08 E	49 38.567 N	18 21.133 E	336	TA	Uí Plocha	204	98
3	Benesov	49 44 27 N	14 38 41 E	49 44.450 N	14 38.683 E	402	TA	Flugplatz	69	252
4	Benesov	49 44 17 N	14 38 42 E	49 44.283 N	14 38.700 E	403	TA	Hangár Bemoair	69	251
5	Bestvina	49 50 10 N	15 35 56 E	49 50.167 N	15 35.933 E		T		12	163
6	Bezůž	50 32 19 N	14 43 14 E	50 32.317 N	14 43.233 E	603	T	Hrad	89	319
7	Břitov	48 56 35 N	15 42 08 E	48 56.583 N	15 42.133 E	428	T	Hrad	111	174
8	Blaník	49 38 36 N	14 52 20 E	49 38.600 N	14 52.333 E	632	T	Rozhledna	59	236
9	Blansko	49 21 06 N	16 38 55 E	49 21.100 N	16 38.917 E	500	T	Nádrží	103	129
10	Blatná	49 25 31 N	13 47 31 E	49 25.517 N	13 47.517 E	454	TA	Flugplatz	139	246

Podhorany, Czech Republic - page 2

Number	Name	Latitude ° , ' , ''	Longitude ° , ' , ''	Latitude ° , ' , ''	Longitude ° , ' , ''	Elevation Meters	Codes *	Description	Distance Km	Bearing
11	Blatná Nádraží	49 25 50 N	13 52 17 E	49 25 833 N	13 52 283 E	430	T	Nádraží	133	246
12	Bohdanec	49 46 38 N	15 13 26 E	49 46 633 N	15 13 433 E	450	T	Kostel Odletový Bod	29	232
13	Bohunovice	49 40 14 N	17 17 42 E	49 40 233 N	17 17 700 E	235	TA	Flugplatz	129	103
14	Boleradice	48 57 45 N	16 50 14 E	48 57 750 N	16 50 233 E	197.8	TA	UI Plocha	143	139
15	Bor u Tachova	49 44 50 N	12 46 41 E	49 44 833 N	12 46 683 E	400	T	Exit 128 - Dálnice Na Rozvadov	200	265
16	Borová	49 44 36 N	16 09 45 E	49 44 600 N	16 09 750 E	650	T	Nádraží	49	116
17	Borek	50 12 35 N	14 39 34 E	50 12 583 N	14 39 567 E	170	TA	UI Plocha	70	296
18	Borítov	49 25 53 N	16 35 31 E	49 25 883 N	16 35 517 E	380	TA	UI Plocha	94	127
19	Boskovice	49 29 29 N	16 39 05 E	49 29 483 N	16 39 083 E	400	T	Nádraží	94	122
20	Bouzov	49 42 20 N	16 53 28 E	49 42 333 N	16 53 467 E	440	T	Hrad	100	105
21	Bramá u Sumpěrka	50 08 49 N	17 00 52 E	50 08 817 N	17 00 867 E	633	T	Nádraží	107	77
22	Brno Medláňky	49 14 13 N	16 33 18 E	49 14 217 N	16 33 300 E	283	TA	Flugplatz	107	137
23	Brno Medláňky Hangár	49 14 25 N	16 33 35 E	49 14 417 N	16 33 583 E	282	TA	Hangár	106	136
24	Brno Turany	49 09 05 N	16 41 38 E	49 09 083 N	16 41 633 E	238	TA	Flugplatz	120	136
25	Broumov	50 33 43 N	16 20 34 E	50 33 717 N	16 20 567 E	408	TA	Flugplatz	89	39
26	Broumov Hangár	50 33 43 N	16 20 34 E	50 33 717 N	16 20 567 E	409	TA	Hangár	89	39
27	Brunál	49 59 38 N	17 28 30 E	49 59 633 N	17 28 500 E	550	T	Nádraží	138	87
28	Breclav	48 47 27 N	16 53 33 E	48 47 450 N	16 53 550 E	162	TA	Flugplatz	160	142
29	Bubovice	49 58 28 N	14 10 41 E	49 58 467 N	14 10 683 E	427	TA	Flugplatz	98	273
30	Buranos Aires	50 00 31 N	14 02 07 E	50 00 516 N	14 02 116 E	440.2	TA	UI Plocha	109	275
31	Býzovec	50 49 33 N	14 16 00 E	50 49 550 N	14 16 000 E	380	TA	UI Plocha	134	318
32	Bystrice nad Pernštejnem	49 31 24 N	16 16 25 E	49 31 400 N	16 16 417 E	532	T	Krizovatka Na Východní Okrají Místa	70	131
33	Čáslav	49 56 24 N	15 23 01 E	49 56 400 N	15 23 017 E	241	TA	Flugplatz	12	271
34	Cerná Hora	49 24 52 N	16 34 42 E	49 24 867 N	16 34 700 E	328	T	Kostel	94	128
35	Cernovice	49 10 35 N	16 39 44 E	49 10 583 N	16 39 733 E	241	TA	Flugplatz	117	136
36	Cervená Lhota	49 14 49 N	14 53 10 E	49 14 817 N	14 53 167 E	480	T	Zámek	91	212
37	Ceská Lípa	50 42 38 N	14 34 05 E	50 42 633 N	14 34 083 E	283	TA	Flugplatz	111	321
38	Ceská Lípa Hangár	50 42 33 N	14 33 20 E	50 42 550 N	14 33 333 E	283	TA	Hangár	111	321
39	Ceská Lípa UI Plocha	50 38 20 N	14 32 30 E	50 38 333 N	14 32 500 E	300	TA	UI Plocha	106	318
40	Ceská Třebová	49 54 31 N	16 27 34 E	49 54 517 N	16 27 567 E	413	TA	UI Plocha	65	93
41	Ceské Budejovice	48 56 48 N	14 25 45 E	48 56 800 N	14 25 750 E	433	TA	Flugplatz	137	217
42	Ceský Dub	50 40 44 N	14 59 57 E	50 40 733 N	14 59 950 E	381	TA	UI Plocha	91	335
43	Ceský Dub Kostel	50 39 38 N	14 59 39 E	50 39 633 N	14 59 650 E	300	T	Kostel	89	334
44	Ceský Krumlov	48 49 21 N	14 19 03 E	48 49 350 N	14 19 050 E	350	T	Nádraží	153	216
45	Cestín	49 48 27 N	15 06 08 E	49 48 450 N	15 06 133 E	500	T	Kostel Naváděcí Bod Pro Přilet Na Rwy 15	35	246
46	Dalice	49 04 12 N	15 27 18 E	49 04 200 N	15 27 300 E	495	TA	UI Plocha	97	184
47	Dalice Kostel	49 04 45 N	15 26 01 E	49 04 750 N	15 26 017 E	577	T	Kostel	96	185
48	Decín	50 46 25 N	14 12 30 E	50 46 417 N	14 12 500 E	400	T	Most Pres Labe - Velký	133	315
49	Detřichov Oáza	49 43 46 N	17 07 00 E	49 43 767 N	17 07 000 E	220	TA	UI Plocha	115	101
50	Dobruška	50 17 22 N	16 09 06 E	50 17 367 N	16 09 100 E	300	T	Nádraží	58	48
51	Dolní Dvůr	48 39 24 N	14 27 04 E	48 39 400 N	14 27 067 E	617	T	Kostel	163	210
52	Domazlice	49 26 22 N	12 55 42 E	49 26 367 N	12 55 700 E	450	T	Kostel	197	255
53	Dusný	50 24 45 N	14 11 52 E	50 24 750 N	14 11 867 E	222	TA	UI Plocha	110	299
54	Dvůr Králové nad Labem	50 24 51 N	15 50 13 E	50 24 850 N	15 50 217 E	283	TA	Flugplatz	57	21
55	Dvůr Králové Hangár	50 24 55 N	15 50 15 E	50 24 917 N	15 50 250 E	282	TA	Hangár	57	21
56	Erpužice	49 48 10 N	13 02 17 E	49 48 167 N	13 02 283 E	479	TA	Flugplatz	181	266
57	Fialník SP4	49 44 31 N	15 10 43 E	49 44 517 N	15 10 717 E	550	T	Lom Odletový Bod	34	231
58	Frydlant	49 35 22 N	18 22 45 E	49 35 367 N	18 22 750 E	439	TA	Flugplatz	207	100
59	Frydlant V Cechách Nádraží	50 55 07 N	15 04 24 E	50 55 117 N	15 04 400 E	500	T	Nádraží	114	343
60	Gořetv Jeníkov	49 49 02 N	15 28 36 E	49 49 033 N	15 28 600 E		T		15	201

Number	Name	Latitude ° , ' , ''	Longitude ° , ' , ''	Latitude ° , ' , ''	Longitude ° , ' , ''	Elevation Meters	Codes [*]	Description	Distance Km	Bearing
61	Habry	49 45 10 N	15 28 59 E	49 45.167 N	15 28.983 E	500	T	Krizovatka Silnic JZ	21	193
62	Havlickův Brod	49 35 50 N	15 32 57 E	49 35.833 N	15 32.950 E	463	TA	Flugplatz	38	180
63	Havlickův Brod Hangár	49 36 00 N	15 33 05 E	49 36.000 N	15 33.083 E	460	TA	Hangár	38	180
64	Herálec	49 41 21 N	15 59 43 E	49 41.350 N	15 59.717 E		T		42	131
65	Hermanův Mestec	49 57 05 N	15 39 31 E	49 57.083 N	15 39.517 E	300	T	Nádraží	7.9	80
66	Hlinsko	49 45 39 N	15 54 05 E	49 45.650 N	15 54.083 E	650	T	Nádraží	32	128
67	Hodkovice Hangár	50 39 26 N	15 04 40 E	50 39.433 N	15 04.667 E	451	TA	Hangár	87	337
68	Hodkovice nad Mohelkou	50 39 26 N	15 04 40 E	50 39.433 N	15 04.667 E	451	TA	Flugplatz	87	337
69	Holesov	49 18 52 N	17 34 08 E	49 18.867 N	17 34.133 E	232	TA	Flugplatz	161	115
70	Horazdovice	49 19 17 N	13 42 33 E	49 19.283 N	13 42.550 E	450	T	Nádraží	149	243
71	Horní Bůza	49 50 23 N	13 21 23 E	49 50.383 N	13 21.383 E	451	T	Kostel	158	267
72	Horní Cerekev	49 18 40 N	15 19 27 E	49 18.667 N	15 19.450 E	586	T	Nádraží	72	193
73	Horní Lhotka Knizovatka	49 46 35 N	15 41 37 E	49 46.583 N	15 41.617 E		T		21	150
74	Horsovský Týn	49 31 27 N	12 56 21 E	49 31.450 N	12 56.350 E	400	T	Nádraží	193	257
75	Hory	50 13 00 N	12 46 30 E	50 13.000 N	12 46.499 E	501.2	TA	UI Plocha	200	280
76	Horice	50 21 26 N	15 34 36 E	50 21.433 N	15 34.600 E	280	TA	Flugplatz	47	2
77	Horice Hangár	50 21 18 N	15 34 35 E	50 21.300 N	15 34.583 E	278	TA	Hangár	46	2
78	Horovice Hangár	49 50 44 N	13 53 14 E	49 50.733 N	13 53.233 E	370	TA	Hangár	120	266
79	Hosín	49 02 24 N	14 29 42 E	49 02.400 N	14 29.700 E	494	TA	Flugplatz	126	218
80	Hosín Hangár	49 02 31 N	14 29 39 E	49 02.517 N	14 29.650 E	492	TA	Hangár	126	218
81	Hradčany	50 37 10 N	14 43 59 E	50 37.167 N	14 43.983 E	278	TA	UI Plocha	95	323
82	Hradec Králové	50 15 12 N	15 50 43 E	50 15.200 N	15 50.717 E	241	TA	Flugplatz	41	31
83	Hradec nad Moravicí	49 52 29 N	17 52 34 E	49 52.483 N	17 52.567 E	300	T	Nádraží	167	92
84	Hranice	49 32 46 N	17 42 16 E	49 32.766 N	17 42.266 E	244	TA	Flugplatz	161	105
85	Hranice Hangár	49 32 52 N	17 42 12 E	49 32.867 N	17 42.200 E	243	TA	Hangár	161	105
86	Humpolec	49 31 35 N	15 20 57 E	49 31.583 N	15 20.950 E	520	T	Dálnice D1 Exit 90	48	198
87	Chabernice	49 44 53 N	15 03 42 E	49 44.883 N	15 03.700 E	351	TA	UI Plocha	41	239
88	Charvatce	50 25 59 N	13 48 38 E	50 25.983 N	13 48.633 E	275	TA	UI Plocha	135	295
89	Cheb Airfield	50 04 46 N	12 24 21 E	50 04.766 N	12 24.350 E	469	TA	Flugplatz	225	275
90	Chlumec nad Cidlinou Zámek	50 09 14 N	15 29 50 E	50 09.233 N	15 29.833 E		T		24	351
91	Chocen	49 58 41 N	16 11 23 E	49 58.683 N	16 11.383 E	266	TA	Flugplatz	46	84
92	Chomutov Tower	50 28 08 N	13 28 05 E	50 28.133 N	13 28.083 E	344	TA	Flugplatz	159	292
93	Chomutov Hangár	50 27 55 N	13 28 02 E	50 27.917 N	13 28.033 E	345	TA	Hangár	159	292
94	Chotebor	49 41 09 N	15 40 34 E	49 41.150 N	15 40.567 E	594	TA	Flugplatz	30	162
95	Chotebor Hangár	49 41 04 N	15 40 44 E	49 41.067 N	15 40.733 E	593	TA	Hangár	30	162
96	Chotec	50 26 00 N	15 31 44 E	50 26.000 N	15 31.733 E	328	TA	UI Plocha	55	358
97	Chotšov	49 39 08 N	13 11 25 E	49 39.133 N	13 11.417 E	360	TA	UI Plocha	172	260
98	Chrást U Chrudimí Rybník	49 53 36 N	15 56 14 E	49 53.600 N	15 56.233 E		T		28	100
99	Chrastava	50 48 48 N	14 57 05 E	50 48.800 N	14 57.083 E	300	T	Nádraží	106	337
100	Chrudim	49 56 11 N	15 46 50 E	49 56.183 N	15 46.833 E	299	TA	Flugplatz	17	91
101	Chrudim Hangár	49 56 14 N	15 47 16 E	49 56.233 N	15 47.267 E	298	TA	Hangár	17	91
102	Chvalovice Komúný	50 01 39 N	15 27 13 E	50 01.650 N	15 27.217 E		T		12	325
103	Jablunné V Podjesitdí	50 46 12 N	14 45 31 E	50 46.200 N	14 45.517 E	600	T	Nádraží	108	329
104	Jaromír	50 19 53 N	15 57 14 E	50 19.883 N	15 57.233 E	274	TA	Flugplatz	52	33
105	Jaromír Hangár	50 20 10 N	15 56 40 E	50 20.167 N	15 56.667 E	271	TA	Hangár	52	32
106	Jaromnice nad Rokytinou	49 05 36 N	15 53 27 E	49 05.600 N	15 53.450 E	422	T	Kostel	97	165
107	Javorník	50 23 41 N	17 00 57 E	50 23.683 N	17 00.950 E	701	T	Nádraží	116	64
108	Jedovnice	49 20 14 N	16 45 10 E	49 20.233 N	16 45.167 E	470	T	Hráz Rybníka - Jz Okraj	109	127
109	Jehnědí	49 57 59 N	16 18 36 E	49 57.983 N	16 18.600 E	478	TA	UI Plocha	54	87
110	Jesenice U Chebu	50 05 04 N	12 28 28 E	50 05.067 N	12 28.467 E	301	T	Hráz Prehrady	220	275

Number	Name	Latitude ° , ' , ''	Longitude ° , ' , ''	Latitude ° , ' , ''	Longitude ° , ' , ''	Elevation Meters	Codes [*]	Description	Distance Km	Bearing
161	Liberec	50 46 06 N	15 01 30 E	50 46.100 N	15 01.500 E	405	TA	Flugplatz	99	338
162	Libice nad Doubravou	49 44 41 N	15 42 11 E	49 44.683 N	15 42.183 E		T		24	153
163	Libina	49 52 44 N	17 05 03 E	49 52.733 N	17 05.050 E	500	T	Kostel	110	93
164	Licimnice	49 55 02 N	15 33 14 E	49 55.033 N	15 33.233 E		T		2.5	173
165	Lichnice	49 52 45 N	15 35 11 E	49 52.750 N	15 35.183 E		T		7.2	159
166	Liň	49 40 31 N	13 16 28 E	49 40.517 N	13 16.467 E	363	TA	Flugplatz	166	261
167	Lipnice	49 36 39 N	15 24 33 E	49 36.650 N	15 24.550 E	600	T	Hrad	38	196
168	Lipávka	49 20 07 N	16 33 08 E	49 20.117 N	16 33.133 E	364	T	Krizovatka "T" Jizní	99	133
169	Litomyšl	49 52 28 N	16 20 07 E	49 52.467 N	16 20.117 E	384	TA	UI Plocha	57	97
170	Lnáře	49 27 16 N	13 47 04 E	49 27.267 N	13 47.067 E	400	T	Zámek	138	248
171	Lomnice N. P.	50 32 22 N	15 23 28 E	50 32.366 N	15 23.466 E	510	TA	UI Plocha	68	350
172	Mantůn	49 59 36 N	13 13 49 E	49 59.600 N	13 13.817 E	430	T	Kostel	166	273
173	Mariánské Lázně	49 55 22 N	12 43 29 E	49 55.367 N	12 43.483 E	540	TA	Flugplatz	202	269
174	Mariánské Lázně Hangár	49 55 22 N	12 43 29 E	49 55.367 N	12 43.483 E	539	TA	Hangár	202	269
175	Mlíník	50 20 35 N	14 26 00 E	50 20.583 N	14 26.000 E	162	TA	UI Plocha	91	300
176	Merín	49 23 25 N	15 53 22 E	49 23.417 N	15 53.367 E	500	T	Kostel	66	158
177	Místec Králové Kostel	50 12 25 N	15 17 48 E	50 12.417 N	15 17.800 E		T		35	329
178	Mikulovice	50 18 06 N	17 17 51 E	50 18.100 N	17 17.850 E	421	TA	Flugplatz	131	71
179	Milevsko	49 26 30 N	14 22 39 E	49 26.500 N	14 22.650 E	400	T	Nádraží	101	237
180	Mirotslav	48 56 00 N	16 18 00 E	48 56.000 N	16 18.000 E	238.1	TA	UI Plocha	124	154
181	Mirotslav Aircon	48 55 56 N	16 20 23 E	48 55.933 N	16 20.383 E	220.1	TA	UI Plocha	126	153
182	Mladá Boleslav	50 23 54 N	14 53 54 E	50 23.900 N	14 53.900 E	238	TA	Flugplatz	69	318
183	Mladá Boleslav Hangár	50 23 52 N	14 53 54 E	50 23.867 N	14 53.900 E	233	TA	Hangár	69	318
184	Mladá Vočice	49 31 56 N	14 48 33 E	49 31.933 N	14 48.550 E	453	T	Kostel	70	230
185	Mnichovo Hradiste	50 32 24 N	15 00 24 E	50 32.400 N	15 00.400 E	244	TA	Flugplatz	77	330
186	Mnichovo Hradiste Hangár	50 32 07 N	14 59 43 E	50 32.117 N	14 59.717 E	244	TA	Hangár	77	329
187	Mohelnice	49 46 51 N	16 56 20 E	49 46.850 N	16 56.333 E	300	T	Nádraží	101	99
188	Moravská Třebová	49 47 54 N	16 41 16 E	49 47.900 N	16 41.267 E	402	TA	Flugplatz	83	100
189	Moravská Třebová Hangár	49 47 49 N	16 40 55 E	49 47.817 N	16 40.917 E	401	TA	Hangár	83	101
190	Most	50 31 30 N	13 40 59 E	50 31.500 N	13 40.983 E	332	TA	Flugplatz	148	297
191	Most Hangár	50 31 30 N	13 40 59 E	50 31.500 N	13 40.983 E	331	TA	Hangár	148	297
192	Most Libkovicce	50 34 15 N	13 41 00 E	50 34.250 N	13 41.000 E	277.1	TA	UI Plocha	150	299
193	Náchod	50 24 50 N	16 07 17 E	50 24.833 N	16 07.283 E	440	TA	UI Plocha	67	37
194	Námíř	49 10 00 N	16 07 34 E	49 10.000 N	16 07.567 E	472	TA	Flugplatz	95	154
195	Nasavrky	49 50 41 N	15 48 12 E	49 50.683 N	15 48.200 E		T	Obec	21	120
196	Nová Bystrice	49 01 09 N	15 06 41 E	49 01.150 N	15 06.683 E	535	T	Nádraží	107	197
197	Nové Místo	50 21 51 N	16 06 49 E	50 21.850 N	16 06.817 E	305	TA	Flugplatz	62	40
198	Nové Místo nad Moraví	49 34 06 N	16 04 55 E	49 34.100 N	16 04.917 E	594	T	Nádraží	56	137
199	Nové Místo nad Metují	50 21 50 N	16 06 50 E	50 21.833 N	16 06.833 E	302	TA	Hangár	62	40
200	Nové Veselí	49 31 11 N	15 54 21 E	49 31.183 N	15 54.350 E	500	T	Hráz	53	151
201	Nový Bydžov	50 14 30 N	15 29 28 E	50 14.500 N	15 29.467 E		T		34	353
202	Nymburk	50 10 10 N	15 03 16 E	50 10.166 N	15 03.266 E	185.9	TA	UI Plocha	44	306
203	Nymburk Nádraží	50 11 36 N	15 02 45 E	50 11.600 N	15 02.750 E	186	TA	Nádraží	46	308
204	Okrský	49 14 55 N	15 46 14 E	49 14.883 N	15 46.233 E	472	T	Nádraží	78	168
205	Olomouc	49 35 16 N	17 12 39 E	49 35.266 N	17 12.650 E	265	TA	Flugplatz	126	107
206	Oparany	49 23 40 N	14 29 05 E	49 23.667 N	14 29.083 E	420	T	Kostel	98	232
207	Opava	49 56 25 N	17 58 59 E	49 56.416 N	17 58.983 E	259.1	TA	UI Plocha	174	89
208	Opočno	50 16 03 N	16 06 49 E	50 16.050 N	16 06.817 E	250	T	Zámek	54	48
209	Ostřany	50 00 56 N	14 46 21 E	50 00.933 N	14 46.350 E	381	TA	UI Plocha	56	279
210	Ostrava Mosnov	49 41 46 N	18 06 39 E	49 41.767 N	18 06.650 E	256	TA	Flugplatz	186	97

Podhorany, Czech Republic - page 6

Number	Name	Latitude ° , ' , ''	Longitude ° , ' , ''	Latitude ° , ' , ''	Longitude ° , ' , ''	Elevation Meters	Codes [*]	Description	Distance Km	Bearing
211	Otrokovice	49 11 54 N	17 31 04 E	49 11 900 N	17 31 067 E	183	TA	Flugplatz	164	119
212	Pacov	49 28 19 N	15 00 13 E	49 28 317 N	15 00 217 E	550	T	Kostel	65	217
213	Pardubice	50 00 48 N	15 44 19 E	50 00 800 N	15 44 316 E	226	TA	Flugplatz	16	59
214	Páčov	49 27 04 N	15 36 39 E	49 27 067 N	15 36 650 E	480	T	Dálnice D1 Exit 112 - Jihlava	54	175
215	Pelhrimov	49 25 08 N	15 13 14 E	49 25 133 N	15 13 233 E	494	T	Nádraží	63	202
216	Pílníkov	50 31 55 N	15 49 11 E	50 31 917 N	15 49 183 E	350	T	Kostel	69	16
217	Písek	49 20 30 N	14 06 45 E	49 20 500 N	14 06 750 E	412	TA	UI Plocha	123	238
218	Pláná Krátenec	49 52 14 N	12 46 21 E	49 52 233 N	12 46 350 E	632	TA	UI Plocha	199	269
219	Plasy	49 55 13 N	13 22 37 E	49 55 216 N	13 22 616 E	436	TA	Flugplatz	156	270
220	Plasy Hangár	49 55 13 N	13 22 37 E	49 55 217 N	13 22 617 E	437	TA	Hangár	156	270
221	Plesnice	49 46 20 N	13 09 47 E	49 46 333 N	13 09 783 E	408.2	TA	UI Plocha	172	265
222	Plzeň Letkov	49 43 23 N	13 27 08 E	49 43 383 N	13 27 133 E	418	TA	Flugplatz	152	262
223	Podhorany	49 56 21 N	15 32 59 E	49 56 350 N	15 32 983 E	381	HSFTA	Flugplatz		
224	Podhorany Hangár	49 56 21 N	15 32 59 E	49 56 350 N	15 32 983 E	382	TA	Hangár		
225	Podhorany Hospoda	49 56 09 N	15 32 13 E	49 56 150 N	15 32 217 E		T		1.0	248
226	Podhorany Krizovatka Na Ronov	49 56 04 N	15 31 58 E	49 56 067 N	15 31 967 E		T		1.3	247
227	Podhorice	49 47 47 N	15 39 20 E	49 47 783 N	15 39 333 E		T		18	154
228	Pohodří	49 49 00 N	16 18 00 E	49 49 000 N	16 18 000 E		T	Stožary	55	104
229	Políčka	49 44 22 N	16 15 32 E	49 44 367 N	16 15 533 E	604	TA	Flugplatz	55	113
230	Políčka Hangár	49 44 03 N	16 15 29 E	49 44 050 N	16 15 483 E	604	TA	Hangár	56	114
231	Polná	49 29 12 N	15 42 12 E	49 29 200 N	15 42 200 E	490	T	Nádraží	52	168
232	Pradřít	50 05 03 N	17 13 55 E	50 05 050 N	17 13 917 E	1491	T	Vyslaň	121	82
233	Praha Kbely	50 07 17 N	14 32 37 E	50 07 283 N	14 32 616 E	286.2	TA	UI Plocha	75	286
234	Praha Letňany	50 07 55 N	14 31 32 E	50 07 883 N	14 31 533 E	277	TA	Flugplatz	76	287
235	Praha Ruzyně	50 06 03 N	14 15 36 E	50 06 050 N	14 15 600 E	381	TA	Flugplatz	94	282
236	Praha Tocná	49 59 07 N	14 25 32 E	49 59 117 N	14 25 533 E	314	TA	Flugplatz	81	274
237	Proseč	49 48 19 N	16 07 00 E	49 48 317 N	16 07 000 E		T		43	110
238	Prostějov	49 26 52 N	17 08 02 E	49 26 867 N	17 08 033 E	213	TA	Flugplatz	126	115
239	Předbor	49 45 58 N	15 42 36 E	49 45 967 N	15 42 600 E		T		22	149
240	Prelouté Kostel	50 02 23 N	15 33 26 E	50 02 383 N	15 33 433 E		T		11	3
241	Prerov	49 25 35 N	17 24 24 E	49 25 583 N	17 24 400 E	207	TA	Flugplatz	145	112
242	Prábram	49 43 12 N	14 06 01 E	49 43 200 N	14 06 017 E	466	TA	Flugplatz	107	257
243	Prábram Hangár	49 43 00 N	14 05 32 E	49 43 000 N	14 05 533 E	456	TA	Hangár	107	257
244	Příbryslav	49 34 50 N	15 45 46 E	49 34 833 N	15 45 767 E	533	TA	Flugplatz	43	159
245	Příbryslav Hangár	49 34 57 N	15 45 33 E	49 34 950 N	15 45 550 E	533	TA	Hangár	42	159
246	Rabštejn	50 02 35 N	13 17 40 E	50 02 583 N	13 17 667 E	550	T	Hrad	162	275
247	Radnice	49 51 28 N	13 36 32 E	49 51 467 N	13 36 533 E	400	T	Kostel	139	267
248	Rakovník	50 05 39 N	13 41 20 E	50 05 650 N	13 41 333 E	387	TA	Flugplatz	134	278
249	Rakovník Hangár	50 05 50 N	13 41 28 E	50 05 833 N	13 41 467 E	388	TA	Hangár	134	278
250	Raná	50 24 14 N	13 45 07 E	50 24 233 N	13 45 117 E	268	TA	Flugplatz	138	293
251	Raná Hangár	50 24 32 N	13 45 22 E	50 24 533 N	13 45 367 E	269	TA	Hangár	138	293
252	Rohozec	49 58 58 N	15 23 31 E	49 58 966 N	15 23 516 E	206	TA	UI Plocha	12	293
253	Rokycany	49 45 00 N	13 35 22 E	49 45 000 N	13 35 366 E	400	TA	UI Plocha	142	262
254	Rokycany Nádraží	49 44 24 N	13 35 31 E	49 44 400 N	13 35 517 E	362	T	Nádraží	142	262
255	Roudnice	50 24 38 N	14 13 34 E	50 24 633 N	14 13 567 E	223	TA	Flugplatz	108	300
256	Rýmarov	49 55 46 N	17 17 05 E	49 55 767 N	17 17 083 E	590	T	Nádraží	124	90
257	Šířmov	48 51 01 N	14 29 28 E	48 51 017 N	14 29 467 E	400	T	Hráz	143	213
258	Sázava UI Plocha	49 53 25 N	14 56 40 E	49 53 417 N	14 56 667 E	410	TA	UI Plocha	44	263
259	Sazená	50 19 29 N	14 15 32 E	50 19 483 N	14 15 533 E	232	TA	Flugplatz	102	295
260	Sec Hráz Prehrady	49 50 16 N	15 39 20 E	49 50 267 N	15 39 333 E		T		14	146

Number	Name	Latitude ° , ' , ''	Longitude ° , ' , ''	Latitude ° , ' , ''	Longitude ° , ' , ''	Elevation Meters	Codes [*]	Description	Distance Km	Bearing
261	Sedláany	49 39 13 N	14 25 36 E	49 39.217 N	14 25.600 E	400	T	Křizovatka Silnic	87	249
262	Semtůi	49 57 35 N	15 30 35 E	49 57.583 N	15 30.583 E		T		3.7	309
263	Skutec	49 49 40 N	16 00 21 E	49 49.667 N	16 00.350 E	488	TA	Flugplatz	35	111
264	Skutec Hangár	49 49 58 N	16 00 03 E	49 49.967 N	16 00.050 E	488	TA	Hangár	34	110
265	Slaný	50 13 00 N	14 05 19 E	50 13.000 N	14 05.317 E	329	TA	Flugplatz	109	287
266	Slavonice	48 59 39 N	15 20 56 E	48 59.650 N	15 20.933 E	512	T	Nádraží	106	188
267	Slezská Harta	49 53 25 N	17 35 06 E	49 53.417 N	17 35.100 E	500	T	Hráz	146	91
268	Sloupno	49 44 12 N	15 45 07 E	49 44.200 N	15 45.117 E		T		27	147
269	Slusovice	49 15 32 N	17 48 50 E	49 15.533 N	17 48.833 E	354	TA	UI Plocha	180	114
270	Soběslav	49 14 48 N	14 42 49 E	49 14.800 N	14 42.817 E	408	TA	Flugplatz	98	218
271	Soběslav Hangár	49 15 02 N	14 42 53 E	49 15.033 N	14 42.883 E	407	TA	Hangár	97	218
272	Sokolov	50 11 11 N	12 38 39 E	50 11.183 N	12 38.650 E	401	T	Nádraží	209	279
273	Stabkov	49 34 00 N	13 02 55 E	49 34.000 N	13 02.917 E	427	TA	Flugplatz	184	258
274	Stabkov Hangár	49 33 55 N	13 03 06 E	49 33.917 N	13 03.100 E	428	TA	Hangár	184	258
275	Stará Paka	50 29 10 N	15 28 10 E	50 29.167 N	15 28.167 E	484	TA	UI Plocha	61	355
276	Staré Sedlo	49 30 16 N	14 11 01 E	49 30.267 N	14 11.017 E	350	T	Most Pres Vltavu Na Orlíku	109	244
277	Stichovice Pluml	49 29 10 N	17 03 20 E	49 29.166 N	17 03.333 E	256	TA	Flugplatz	119	114
278	Strachovice	48 48 27 N	16 09 45 E	48 48.450 N	16 09.750 E	211.8	TA	UI Plocha	133	160
279	Strakonice	49 15 06 N	13 53 34 E	49 15.100 N	13 53.567 E	420	TA	Flugplatz	142	238
280	Strakonice Hangár	49 15 19 N	13 53 30 E	49 15.317 N	13 53.500 E	420	TA	Hangár	142	238
281	Strunkovice	49 04 57 N	14 04 33 E	49 04.950 N	14 04.550 E	479	TA	Flugplatz	143	229
282	Strunkovice Hangár	49 04 59 N	14 04 33 E	49 04.983 N	14 04.550 E	477	TA	Hangár	143	229
283	Susice	49 14 02 N	13 29 13 E	49 14.033 N	13 29.217 E	670	T	Vysílač Západní Od Místa	168	243
284	Svetlá nad Sázavou	49 40 08 N	15 25 01 E	49 40.133 N	15 25.017 E	400	T	Nádraží	32	198
285	Svitavy	49 45 20 N	16 28 34 E	49 45.333 N	16 28.567 E	435	T	Sílo	69	107
286	Sternberk	49 43 13 N	17 17 12 E	49 43.217 N	17 17.200 E	350	T	Nádraží	127	100
287	Stichovice	49 29 10 N	17 03 20 E	49 29.167 N	17 03.333 E	255	TA	UI Plocha	119	114
288	Stýř	49 57 44 N	16 45 42 E	49 57.733 N	16 45.700 E	450	T	Kostel	87	88
289	Šumperk	49 57 38 N	17 01 04 E	49 57.633 N	17 01.067 E	335	TA	Flugplatz	105	88
290	Šumperk Hangár	49 57 48 N	17 01 09 E	49 57.800 N	17 01.150 E	335	TA	Hangár	105	88
291	Tábor	49 23 28 N	14 42 30 E	49 23.467 N	14 42.500 E	439	TA	Flugplatz	86	225
292	Tábor Hangár	49 23 39 N	14 42 10 E	49 23.650 N	14 42.167 E	428	TA	Hangár	86	225
293	Tábor Vsechov	49 26 19 N	14 37 25 E	49 26.317 N	14 37.417 E	493	TA	UI Plocha	87	230
294	Tachov Nádraží	49 48 09 N	12 38 20 E	49 48.150 N	12 38.333 E	370	T	Nádraží	209	267
295	Tachov UI Plocha	49 47 50 N	12 42 25 E	49 47.833 N	12 42.417 E	500	TA	UI Plocha	204	267
296	Telc	49 10 55 N	15 27 51 E	49 10.917 N	15 27.850 E	514	T	Nádraží	84	184
297	Teplá	49 58 29 N	12 51 28 E	49 58.483 N	12 51.467 E	600	T	Nádraží	193	272
298	Teplice	50 37 18 N	13 48 40 E	50 37.300 N	13 48.666 E	350	TA	UI Plocha	145	302
299	Tisnov	49 20 51 N	16 25 05 E	49 20.850 N	16 25.083 E	270	T	Nádraží	91	136
300	Toužim	50 05 11 N	12 57 10 E	50 05.183 N	12 57.167 E	652	TA	Flugplatz	186	276
301	Toužim Hangár	50 05 11 N	12 57 10 E	50 05.183 N	12 57.167 E	651	TA	Hangár	186	276
302	Trhová Kamenice	49 47 13 N	15 49 00 E	49 47.217 N	15 49.000 E		T	Obec	26	131
303	Trhové Sviny	48 50 17 N	14 38 15 E	48 50.283 N	14 38.250 E	500	T	Kostel	139	209
304	Třebíč	49 46 13 N	15 16 13 E	49 46.217 N	15 16.217 E	550	T	Kostel Navádící Bod Pro Průlet Na Rwy 33	27	227
305	Třebíč	49 11 54 N	15 54 10 E	49 11.900 N	15 54.167 E	486	TA	UI Plocha	86	163
306	Tremotínice Komín nad Benz. Pumpou	49 52 24 N	15 34 56 E	49 52.400 N	15 34.933 E		T		7.7	162
307	Týn nad Vltavou	49 13 21 N	14 25 21 E	49 13.350 N	14 25.350 E	350	T	Most Pres Vltavu	114	226
308	Uherské Hradišti	49 01 46 N	17 26 23 E	49 01.767 N	17 26.383 E	177	TA	Flugplatz	170	126
309	Uháské Janovice	49 52 56 N	15 03 33 E	49 52.933 N	15 03.550 E	389	T	Nádraží	36	260
310	Usov	49 47 54 N	17 00 40 E	49 47.900 N	17 00.667 E	300	T	Kostel	106	98

Number	Name	Latitude ° , ' , ''	Longitude ° , ' , ''	Latitude ° , ' , ''	Longitude ° , ' , ''	Elevation Meters	Codes [*]	Description	Distance Km	Bearing
311	Ustí N. L.	50 42 00 N	13 58 18 E	50 42 000 N	13 58 300 E	241	TA	UI Plocha	140	308
312	Ustí nad Labem	50 39 19 N	14 02 43 E	50 39 317 N	14 02 717 E	280	T	Most Pres Labe	133	307
313	Ustí nad Orlicí	49 58 43 N	16 25 35 E	49 58 717 N	16 25 583 E	408	TA	Flugplatz	63	86
314	Ustí nad Orlicí Hangár	49 58 46 N	16 25 21 E	49 58 767 N	16 25 350 E	409	TA	Hangár	63	86
315	Valeč	50 10 28 N	13 15 08 E	50 10 467 N	13 15 133 E	500	T	Kostel	166	280
316	Velesín Kostel	48 49 45 N	14 27 46 E	48 49 750 N	14 27 767 E	350	T	Kostel	146	213
317	Velesín UI Plocha	48 49 36 N	14 26 58 E	48 49 600 N	14 26 967 E	518	TA	UI Plocha	147	213
318	Velká Bystřice	49 35 52 N	17 21 58 E	49 35 867 N	17 21 967 E	260	T	Nádraží	136	106
319	Velké Dářko	49 37 54 N	15 54 13 E	49 37 900 N	15 54 217 E	590	T	Hráz - Jizní Okraj	43	143
320	Velké Meziříčí	49 21 38 N	16 00 53 E	49 21 633 N	16 00 883 E	500	T	Dálniční Most	73	152
321	Velké Porfíř	50 28 04 N	16 12 20 E	50 28 067 N	16 12 333 E	405	TA	Flugplatz	75	38
322	Velké Porfíř - Hronov	50 28 04 N	16 12 20 E	50 28 067 N	16 12 333 E	404	TA	Hangár	75	38
323	Vemýrov	49 50 50 N	15 09 11 E	49 50 833 N	15 09 183 E	450	T	Krizovatka Naváděcí Bod Pro Prilet Na Rwy 15	30	250
324	Vetmý Jeníkov	49 28 25 N	15 28 41 E	49 28 417 N	15 28 683 E	650	T	Kostel	52	186
325	Vimperk	49 03 08 N	13 46 29 E	49 03 133 N	13 46 483 E	500	T	Kostel	162	233
326	Vír	49 33 51 N	16 18 32 E	49 33 850 N	16 18 533 E	600	T	Hráz	69	127
327	Vlasim	49 43 44 N	14 52 44 E	49 43 733 N	14 52 733 E	433	TA	Flugplatz	53	244
328	Vlasim Hangár	49 43 44 N	14 52 44 E	49 43 733 N	14 52 733 E	433	TA	Hangár	53	244
329	Vodochody	50 13 00 N	14 23 44 E	50 13 000 N	14 23 733 E	280	TA	Flugplatz	88	291
330	Vojnov Místec	49 40 46 N	15 52 47 E	49 40 767 N	15 52 783 E	500	T	Flugplatz	37	141
331	Votice	49 38 16 N	14 39 04 E	49 38 267 N	14 39 067 E	500	T	Krizovatka Silnic Severovýchodní	73	243
332	Vranov nad Dyjí	48 54 25 N	15 49 07 E	48 54 417 N	15 49 117 E	400	T	Hráz	116	170
333	Vrchlabí	50 37 27 N	15 38 47 E	50 37 450 N	15 38 783 E	491	TA	Flugplatz	76	5
334	Vrchlabí Hangár	50 37 26 N	15 38 43 E	50 37 433 N	15 38 717 E	491	TA	Hangár	76	5
335	Vsechov	49 26 11 N	14 37 15 E	49 26 183 N	14 37 250 E	492	TA	Hangár	87	230
336	Vyskytna	49 25 40 N	15 21 51 E	49 25 667 N	15 21 850 E	650	T	Kostel	58	193
337	Vysoké Mýto	49 55 37 N	16 11 09 E	49 55 617 N	16 11 150 E	302	TA	Flugplatz	46	91
338	Vysoké Mýto Hangár	49 56 03 N	16 10 34 E	49 56 050 N	16 10 567 E	301	TA	Hangár	45	90
339	Vyskov	49 18 01 N	17 01 31 E	49 18 017 N	17 01 517 E	280	TA	Flugplatz	128	123
340	Vyskov Hangár	49 18 01 N	17 01 17 E	49 18 017 N	17 01 283 E	279	TA	Hangár	128	123
341	Výšší Brod	48 36 49 N	14 18 45 E	48 36 817 N	14 18 750 E	600	T	Kostel	173	212
342	Zábřeh	49 55 44 N	18 04 45 E	49 55 733 N	18 04 750 E	226	TA	Flugplatz	181	91
343	Zbohov	49 49 18 N	15 37 20 E	49 49 300 N	15 37 333 E	493	T	Fluplatz	14	158
344	Zbraslavice	49 48 51 N	15 12 06 E	49 48 850 N	15 12 100 E	493	TA	Fluplatz	29	241
345	Zbraslavice Hangár	49 49 00 N	15 12 10 E	49 49 000 N	15 12 167 E	483	TA	Hangár Odletový Bod	28	241
346	Zlín Stípa	49 16 23 N	17 44 52 E	49 16 383 N	17 44 867 E	336	TA	UI Plocha	175	114
347	Znojmo	48 49 04 N	16 03 57 E	48 49 066 N	16 03 950 E	253	TA	Flugplatz	130	163
348	Znojmo Nádraží	48 51 08 N	16 03 32 E	48 51 133 N	16 03 533 E	290	T	Nádraží	126	163
349	Zruč nad Sázavou	49 44 24 N	15 06 19 E	49 44 400 N	15 06 317 E	457	TA	Nádraží	39	235
350	Zruč nad Sázavou Nádraží	49 44 17 N	15 06 15 E	49 44 283 N	15 06 250 E	380	TA	Nádraží Odletový Bod	39	235
351	Zvíkovec	49 57 34 N	13 41 45 E	49 57 567 N	13 41 750 E	323	T	Most Pres Berounku	133	272
352	Zamberk	50 05 02 N	16 26 38 E	50 05 033 N	16 26 633 E	725	TA	Flugplatz	66	76
353	Zatec	50 18 58 N	13 31 08 E	50 18 967 N	13 31 133 E	273	TA	UI Plocha	151	287
354	Zdár nad Sázavou	49 33 14 N	15 56 05 E	49 33 233 N	15 56 083 E	447	T	UI Plocha	51	147
355	Zdřec nad Doubravou Krizovatka	49 41 35 N	15 47 51 E	49 41 583 N	15 47 850 E	500	T	Kostel	33	147
356	Zeletava	49 08 22 N	15 40 15 E	49 08 367 N	15 40 250 E	578	T	Kostel	89	174
357	Zeliv	49 31 21 N	15 13 07 E	49 31 350 N	15 13 117 E	406	T	Hráz	52	207
358	Zelivská	49 40 41 N	15 08 53 E	49 40 683 N	15 08 883 E	447	T	Most Pres Prehradu	41	225
359	Zleby	49 53 22 N	15 29 07 E	49 53 367 N	15 29 117 E	500	T	Obec	7.2	220
360	Zlúčice	50 05 08 N	13 07 36 E	50 05 133 N	13 07 600 E	500	T	Hráz	174	276

Codes*

- A: Airport
- F: Finish Point
- H: Home airport
- S: Start Point
- T: Turnpoint