

Worldwide Soaring Turnpoint Exchange

Unofficial Coordinates for the Finnish Control Points

Courtesy of Aku Jaakkola (aku.jaakkola@gmail.com)

Dated: 27 January 2018

Magnetic Variation: 7.5E

Time zone: EET, Summer offset from GMT is 3:00 and in Winter it is 2:00.

Printed Saturday, 21 April 2018 at 14:31 GMT

UNOFFICIAL, USE AT YOUR OWN RISK

Do not use for navigation, for flight verification only.

Always consult the relevant publications for current and correct information.

This service is provided free of charge with no warranties, expressed or implied.

User assumes all risk of use.

<i>Number</i>	<i>Name</i>	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Elevation</i> METERS	<i>Codes</i> *	<i>Comment</i>	<i>ID</i>	<i>Distance</i> Km	<i>Bearing</i>
503	Ahmosuo	64 53 43 N	25 45 08 E	64 53.717 N	25 45.133 E	29	AT	airfield	503AHMOS	469	17
150	Ahtari	62 32 49 N	24 04 02 E	62 32.817 N	24 04.033 E	157	T	bridge	150AHTAR	201	7
137	Ajoniemi	60 25 04 N	23 26 43 E	60 25.067 N	23 26.717 E	81	T	crossroads	137AJEMI	52	233
613	Alaharma	63 14 44 N	22 51 24 E	63 14.733 N	22 51.400 E	31	T	church	613ALRMA	286	355
151	Alajarvi	62 59 45 N	23 49 01 E	62 59.750 N	23 49.017 E	100	T	bridge	151ALAJA	251	4
106	Alavus	62 33 17 N	23 34 24 E	62 33.283 N	23 34.400 E	124	AT	airfield	106ALAVU	204	360
26	Alvettula	61 12 11 N	24 29 19 E	61 12.183 N	24 29.317 E	86	T	bridge	026ALVET	55	29
92	Anttila	61 03 54 N	26 49 46 E	61 03.900 N	26 49.767 E	116	T	crossroads	092ANTTI	151	83
52	Artjarvi	60 44 37 N	26 03 21 E	60 44.617 N	26 03.350 E	88	T	T-junction	052ARTJA	105	97
202	Aura	60 38 51 N	22 35 22 E	60 38.850 N	22 35.367 E	41	T	railway bridge	202AURA	84	271
102	EFFO	60 48 07 N	23 38 42 E	60 48.117 N	23 38.700 E	99	AT	airfield	102EFFO	27	292
64	EFJM	61 46 43 N	22 42 58 E	61 46.717 N	22 42.967 E	154	AT	airfield	064EFJM	137	335
62	Elimaki	60 43 31 N	26 24 59 E	60 43.517 N	26 24.983 E	43	T	T-junction	062ELIMA	125	98
344	Eno	62 48 13 N	30 09 24 E	62 48.217 N	30 09.400 E	112	T	bridge	344ENO	391	59
55	Eraslahti	61 42 34 N	24 37 57 E	61 42.567 N	24 37.950 E	141	T	RR embank	055ERASL	111	22

<i>Number</i>	<i>Name</i>	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Elevation</i> <i>METERS</i>	<i>Codes</i> [*]	<i>Comment</i>	<i>ID</i>	<i>Distance</i> <i>Km</i>	<i>Bearing</i>
104	Eura	61 06 58 N	22 12 05 E	61 06.967 N	22 12.083 E	79	AT	airfield	104EURA	112	300
152	Evijarvi	63 21 36 N	23 27 52 E	63 21.600 N	23 27.867 E	83	T	crossroads	152EVIJA	293	1
7	Forssa	60 49 31 N	23 35 03 E	60 49.517 N	23 35.050 E	106	T	crossroads	007FORSS	30	295
107	Haapajarvi	63 42 42 N	25 23 42 E	63 42.700 N	25 23.700 E	107	AT	airfield	107HPJRV	337	18
108	Haapamaki	62 15 16 N	24 20 52 E	62 15.267 N	24 20.867 E	162	T	abandoned airfield	108HPMKI	169	12
506	Haapavesi	64 06 47 N	25 30 15 E	64 06.783 N	25 30.250 E	96	AT	airfield	506HAAPA	381	18
952	Hailuoto	64 58 01 N	24 42 16 E	64 58.017 N	24 42.267 E	2	AT	airfield	952EFHL	471	11
907	Halli	61 51 16 N	24 48 09 E	61 51.267 N	24 48.150 E	146	AT	VOR/DME HALLI	907EFHA	129	24
601	Halsua	63 27 48 N	24 10 03 E	63 27.800 N	24 10.050 E	129	T	crossroads	601HASUA	303	8
39	Hameenkoski	61 00 46 N	25 10 16 E	61 00.767 N	25 10.267 E	114	T	T-junction	039HKOSK	64	69
109	Hameenkyro	61 41 25 N	23 04 27 E	61 41.417 N	23 04.450 E	137	AT	airfield	109HMNKR	119	340
19	Hameenlinna	60 58 16 N	24 28 24 E	60 58.267 N	24 28.400 E	116	T	crossroads	019HAMEE	32	44
139	Hanhilammi	60 40 50 N	24 35 29 E	60 40.833 N	24 35.483 E	129	T	very small lake	139HAMMI	27	112
347	Hankamaki	63 20 34 N	28 27 49 E	63 20.567 N	28 27.817 E	123	T	crossroads	347HANKA	367	44
329	Hankasalmi	62 21 26 N	26 33 54 E	62 21.433 N	26 33.900 E	119	T	crossroads	329HANKA	221	42
953	Hanko	59 50 44 N	23 04 56 E	59 50.733 N	23 04.933 E	6	AT	airfield	953EFHN	115	218
65	Hartola	61 34 46 N	26 00 26 E	61 34.767 N	26 00.433 E	131	T	crossroads	065HARTO	138	54
15	Hattula	61 03 48 N	24 23 32 E	61 03.800 N	24 23.533 E	85	T	bridge	015HATTU	39	30
153	Hauho	61 10 38 N	24 33 49 E	61 10.633 N	24 33.817 E	121	T	T-junction	153HAUHO	54	34
328	Haukivuori	62 01 07 N	27 12 16 E	62 01.117 N	27 12.267 E	119	T	bridge	328HAUKI	217	55
89	Heinamaa	60 52 14 N	25 49 11 E	60 52.233 N	25 49.183 E	105	T	crossroads	089HEINA	93	88
337	Heinavesi	62 25 26 N	28 38 05 E	62 25.433 N	28 38.083 E	102	T	crossroads	337HEINA	303	57
901	Helsinki	60 20 16 N	24 57 13 E	60 20.267 N	24 57.217 E	55	AT	VOR/DME HELSNK	901EFHK	64	142
101	Hietanen	61 35 03 N	27 00 39 E	61 35.050 N	27 00.650 E	102	T	railway brg	101HIETA	181	65
29	Hiidenvesi	60 21 42 N	24 10 13 E	60 21.700 N	24 10.217 E	37	T	bridge	029HIIDE	42	184
326	Hirola	61 45 52 N	27 18 41 E	61 45.867 N	27 18.683 E	99	T	highway	326HIIRO	205	62
701	Hirsila	61 44 08 N	24 19 41 E	61 44.133 N	24 19.683 E	119	T	T-junction	701HIRSI	111	13
604	Hoisko	63 01 58 N	23 52 21 E	63 01.967 N	23 52.350 E	111	T	crossroads	604HOSKO	255	5
40	Hollola	60 58 54 N	25 29 12 E	60 58.900 N	25 29.200 E	112	T	T-junction	040HOLLO	79	77
155	Honkajoki	61 59 37 N	22 15 22 E	61 59.617 N	22 15.367 E	101	T	bridge	155HONKA	171	333
54	Honkilahti	60 58 22 N	22 07 58 E	60 58.367 N	22 07.967 E	64	T	crossroads	054HONKI	111	292
22	Humppila	60 57 13 N	23 20 22 E	60 57.217 N	23 20.367 E	102	T	crossroads	022HUMPP	48	307
21	Hyvinkaa	60 39 11 N	24 52 53 E	60 39.183 N	24 52.883 E	131	AT	airfield	021HYVIN	43	111
303	Iisalmi	63 37 55 N	27 07 20 E	63 37.917 N	27 07.333 E	117	AT	airfield	303IISAL	357	32
130	Iittala	61 04 56 N	24 08 13 E	61 04.933 N	24 08.217 E	91	T	bridge	130IITTA	38	9
156	Ikaalinen	61 46 35 N	23 01 12 E	61 46.583 N	23 01.200 E	141	T	Spa bldg	156IKAAL	129	341
610	Ilmajoki	62 43 38 N	22 33 47 E	62 43.633 N	22 33.783 E	41	T	church	610ILOKI	235	348
345	Ilomantsi	62 39 57 N	30 56 22 E	62 39.950 N	30 56.367 E	145	T	bridge	345ILOMA	418	64
105	Immola	61 14 59 N	28 54 13 E	61 14.983 N	28 54.217 E	103	AT	airfield	105IMMOL	264	83
49	Iso Evo	61 11 40 N	25 06 28 E	61 11.667 N	25 06.467 E	121	T	schoolbuldng	049ISOEV	73	54
157	Isojoki	62 06 42 N	21 57 09 E	62 06.700 N	21 57.150 E	105	T	bridge	157ISOJO	191	331

Number	Name	Latitude ° , ' , ''	Longitude ° , ' , ''	Latitude ° , ' , ''	Longitude ° , ' , ''	Elevation METERS	Codes *	Comment	ID	Distance Km	Bearing
63	Jaala	61 02 58 N	26 29 22 E	61 02.967 N	26 29.367 E	133	T	church	063JAALA	133	82
77	Jalasjarvi	62 30 31 N	22 43 32 E	62 30.517 N	22 43.533 E	107	T	T-junction	077JALAS	210	348
159	Jami	61 49 14 N	22 42 21 E	61 49.233 N	22 42.350 E	145	T	T-junction	159JAMI	142	336
148	Jaminkipohja	61 53 38 N	24 06 43 E	61 53.633 N	24 06.717 E	141	T	crossroads	148JAMIN	128	7
149	Jamsa	61 51 07 N	25 10 43 E	61 51.117 N	25 10.717 E	140	T	crossroads	149JAMSA	136	32
334	Jappila	62 22 37 N	27 26 21 E	62 22.617 N	27 26.350 E	111	T	crossroads	334JAPPI	253	50
32	Jarvela	60 52 50 N	25 16 07 E	60 52.833 N	25 16.117 E	112	T	crossroads	032JARVE	64	83
910	Joensuu	62 39 38 N	29 36 38 E	62 39.633 N	29 36.633 E	121	AT	VOR/DME JOSIE	910EFJO	359	59
323	Joutsa	61 44 59 N	26 06 32 E	61 44.983 N	26 06.533 E	129	T	T-junction	323JOUTS	155	50
162	Juokslahti	61 55 57 N	25 20 52 E	61 55.950 N	25 20.867 E	80	T	bridge	162JUOKS	148	33
518	Juorkuna	64 57 20 N	26 59 04 E	64 57.333 N	26 59.067 E	107	T	T-junction	518JUORK	490	23
520	Jurmu	65 29 55 N	27 56 05 E	65 29.917 N	27 56.083 E	155	T	T-junction	520JURMU	562	26
163	Jurva	62 40 33 N	21 58 55 E	62 40.550 N	21 58.917 E	75	T	T-junction	163JURVA	243	341
346	Juuka	63 14 53 N	29 16 14 E	63 14.883 N	29 16.233 E	116	T	T-junction	346JUUKA	387	49
82	Juva	61 53 54 N	27 48 11 E	61 53.900 N	27 48.183 E	94	T	crossroads	082JUVA	235	63
909	Jyvaskyla	62 25 15 N	25 37 24 E	62 25.250 N	25 37.400 E	140	AT	VOR/DME LUONET	909EFJY	203	30
341	Kaavi	62 58 33 N	28 29 48 E	62 58.550 N	28 29.800 E	107	T	T-junction	341KAAVI	338	48
391	Kajaani	64 16 57 N	27 39 21 E	64 16.950 N	27 39.350 E	147	AT	VOR/DME KAINUU	391EFKI	433	31
955	Kalajoki	64 13 43 N	23 49 35 E	64 13.717 N	23 49.583 E	13	AT	airfield	955EFKO	388	5
164	Kalakoski	62 28 00 N	23 05 47 E	62 28.000 N	23 05.783 E	129	T	bridge	164KALAK	199	352
165	Kalkkinen	61 17 29 N	25 40 22 E	61 17.483 N	25 40.367 E	132	T	Canal	165KALKK	104	61
205	Kallisuo	60 19 05 N	22 43 35 E	60 19.083 N	22 43.583 E	56	T	Crossroads	205KASUO	90	246
136	Kangasala	61 27 49 N	24 04 18 E	61 27.817 N	24 04.300 E	96	T	crossroads	136KANGA	80	6
76	Kangasniemi	61 59 54 N	26 38 55 E	61 59.900 N	26 38.917 E	100	T	bridge	076KANGA	194	50
68	Kankaanpaa	61 49 04 N	22 22 06 E	61 49.067 N	22 22.100 E	136	T	crossroads	068KANKA	152	330
110	Kannus	63 55 14 N	24 05 12 E	63 55.233 N	24 05.200 E	103	AT	airfield	110KANNU	353	7
85	Kanteenmaa	61 03 44 N	22 56 13 E	61 03.733 N	22 56.217 E	94	T	crossroads	085KANTE	73	307
702	Kapee	61 48 41 N	23 50 14 E	61 48.683 N	23 50.233 E	100	T	T-junction	702KAPEE	120	0
17	Karjaa	60 04 41 N	23 43 42 E	60 04.683 N	23 43.700 E	46	T	crossroads	017KARJA	77	204
141	Karjalohja	60 14 25 N	23 43 04 E	60 14.417 N	23 43.067 E	63	T	crossroads	141KAHJA	60	209
6	Karkkila	60 31 59 N	24 14 20 E	60 31.983 N	24 14.333 E	105	T	crossroads	006KRKKL	24	172
11	Karkola	60 38 46 N	23 52 23 E	60 38.767 N	23 52.383 E	109	T	T-junction	011KARKO	17	239
505	Karsamaki	63 59 21 N	25 44 37 E	63 59.350 N	25 44.617 E	106	AT	airfield	505KARSA	371	20
145	Karstula	62 52 28 N	24 47 57 E	62 52.467 N	24 47.950 E	131	T	crossroads	145KARST	240	16
167	Karvia	62 07 59 N	22 33 28 E	62 07.983 N	22 33.467 E	120	T	T-junction	167KARVI	175	340
168	Kauhajarvi	62 12 47 N	22 17 53 E	62 12.783 N	22 17.883 E	124	T	T-junction	168KHJRV	190	338
111	Kauhajoki	62 27 48 N	22 23 28 E	62 27.800 N	22 23.467 E	124	AT	airfield	111KHJKI	212	343
914	Kauhava	63 07 21 N	23 03 21 E	63 07.350 N	23 03.350 E	46	AT	VOR/DME KAUHAV	914EFKA	270	356
58	Kausala	60 53 40 N	26 20 14 E	60 53.667 N	26 20.233 E	80	T	crossroads	058KAUSA	121	89
169	Kautunvuolle	61 57 25 N	24 06 25 E	61 57.417 N	24 06.417 E	137	T	bridge	169KAUTU	135	7
84	Keitele	63 11 17 N	26 20 27 E	63 11.283 N	26 20.450 E	99	T	bridge	084KEITE	296	30

<i>Number</i>	<i>Name</i>	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Elevation</i> <i>METERS</i>	<i>Codes</i> [*]	<i>Comment</i>	<i>ID</i>	<i>Distance</i> <i>Km</i>	<i>Bearing</i>
969	Kemi	65 46 45 N	24 35 05 E	65 46.750 N	24 35.083 E	18	AT	airfield	969EFKE	561	10
956	Kemijarvi	66 42 57 N	27 09 26 E	66 42.950 N	27 09.433 E	211	AT	airfield	956EFKM	681	19
10	Keritty	60 41 36 N	24 07 00 E	60 41.600 N	24 07.000 E	123	T	island	010KERIT	5.5	188
170	Keuruu	62 15 28 N	24 40 31 E	62 15.467 N	24 40.517 E	101	T	railway bridge	170KEURU	171	17
171	Kihnio	62 11 52 N	23 10 33 E	62 11.867 N	23 10.550 E	125	T	T-junction	171KIHNI	169	351
16	Kiikala	60 27 44 N	23 39 05 E	60 27.733 N	23 39.083 E	116	AT	airfield	016KIIKA	40	227
172	Killinkoski	62 23 24 N	23 52 48 E	62 23.400 N	23 52.800 E	148	T	bridge	172KILLI	184	4
330	Kilpola	61 50 21 N	27 39 43 E	61 50.350 N	27 39.717 E	95	T	T-junction	330KILPO	225	63
192	Kilvakkala	61 45 32 N	23 00 38 E	61 45.533 N	23 00.633 E	111	T	crossroads	192KIALA	128	340
519	Kipina	65 16 07 N	26 33 12 E	65 16.117 N	26 33.200 E	110	T	T-junction	519KIPIN	518	20
33	Kisakeskus	60 07 09 N	23 22 45 E	60 07.150 N	23 22.750 E	50	T	crossroads	033KISAK	80	218
304	Kitee	62 09 58 N	30 04 25 E	62 09.967 N	30 04.417 E	111	AT	airfield	304KITEE	354	68
305	Kiuruvesi	63 42 20 N	26 36 59 E	63 42.333 N	26 36.983 E	157	AT	airfield	305KIURU	354	28
113	Kivijarvi	63 07 31 N	25 07 27 E	63 07.517 N	25 07.450 E	153	AT	airfield	113KIVIJ	270	18
521	Kokkokyla	65 41 32 N	26 40 45 E	65 41.533 N	26 40.750 E	128	T	T-junction	521KOKKO	565	19
971	Kokkola	63 43 13 N	23 08 21 E	63 43.217 N	23 08.350 E	26	AT	airfield	971EFKK	335	359
71	Kolho	62 07 51 N	24 30 13 E	62 07.850 N	24 30.217 E	102	T	bridge	071KOLHO	156	15
703	Korkeakoski	61 48 33 N	24 22 40 E	61 48.550 N	24 22.667 E	124	T	Railway crossing	703KRKSK	119	14
147	Korpilahti	62 01 58 N	25 35 55 E	62 01.967 N	25 35.917 E	131	T	T-junction	147KORPI	164	36
191	Korri	61 07 24 N	25 38 26 E	61 07.400 N	25 38.433 E	87	T	gas station	191KORRI	93	70
608	Kortesjarvi	63 17 59 N	23 09 21 E	63 17.983 N	23 09.350 E	60	T	church	608KORVI	289	358
91	Koskenniska	61 04 58 N	26 11 08 E	61 04.967 N	26 11.133 E	98	T	bridge	091KOSKE	118	78
174	Koskenpaa	62 04 34 N	25 09 49 E	62 04.567 N	25 09.817 E	113	T	bridge	174KOSKE	158	28
25	Koski	60 40 37 N	23 06 00 E	60 40.617 N	23 06.000 E	98	T	crossroads	025KOSKI	56	270
602	Koskue	62 21 37 N	22 50 26 E	62 21.617 N	22 50.433 E	116	T	crossroads	602KOKUE	192	347
127	Kovenlahti	61 54 23 N	22 50 23 E	61 54.383 N	22 50.383 E	137	T	crossroads	127KOVEN	146	340
957	Kuhmo	64 06 45 N	29 26 19 E	64 06.750 N	29 26.317 E	174	AT	airfield	957EFKH	464	41
175	Kuhmoinen	61 33 28 N	25 11 01 E	61 33.467 N	25 11.017 E	100	T	bridge	175KUHMO	107	39
958	Kumlinge	60 14 49 N	20 48 17 E	60 14.817 N	20 48.283 E	2	AT	airfield	958EFKG	190	262
129	Kunikaanlahde	61 46 32 N	22 31 41 E	61 46.533 N	22 31.683 E	143	T	swimming pool	129KUNIN	143	332
37	Kuohijoki	61 18 11 N	24 47 49 E	61 18.183 N	24 47.817 E	93	T	bridge	037KUOHI	72	38
911	Kuopio	62 58 47 N	27 48 50 E	62 58.783 N	27 48.833 E	98	AT	VOR/DME VEHKAA	911EFKU	315	44
176	Kuortane	62 49 10 N	23 30 18 E	62 49.167 N	23 30.300 E	96	T	building	176KUORT	233	360
100	Kuortti	61 25 09 N	26 26 04 E	61 25.150 N	26 26.067 E	91	T	crossroads	100KUORT	146	65
177	Kurikka	62 37 13 N	22 24 25 E	62 37.217 N	22 24.417 E	50	T	bridge	177KURIK	227	345
178	Kuru	61 53 07 N	23 44 08 E	61 53.117 N	23 44.133 E	100	T	bridge	178KURU	129	359
972	Kuusamo	65 59 25 N	29 13 55 E	65 59.417 N	29 13.917 E	264	AT	airfield	972EFKS	636	29
70	Kuusjoki	60 35 12 N	23 15 14 E	60 35.200 N	23 15.233 E	104	T	tower	070KUUSJ	50	258
99	Kymi	60 34 17 N	26 53 46 E	60 34.283 N	26 53.767 E	68	AT	airfield	099KYMI	153	103
179	Kyyjarvi	63 02 35 N	24 33 38 E	63 02.583 N	24 33.633 E	122	T	crossroads	179KYYJA	257	12
86	Laajoki	60 51 05 N	22 05 35 E	60 51.083 N	22 05.583 E	81	T	crossroads	086LAAJO	111	285

<i>Number</i>	<i>Name</i>	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Elevation</i> <i>METERS</i>	<i>Codes</i> [*]	<i>Comment</i>	<i>ID</i>	<i>Distance</i> <i>Km</i>	<i>Bearing</i>
134	Laakasalo	60 44 10 N	24 10 07 E	60 44.167 N	24 10.117 E	122	T	building	134LAAKA	2.8	112
142	Lahnajarvi	60 22 17 N	23 42 28 E	60 22.283 N	23 42.467 E	83	T	crossroads	142LARVI	47	216
143	Lahti	60 58 35 N	25 39 32 E	60 58.583 N	25 39.533 E	106	T	railway station	143LAHTI	87	80
78	Laitila	60 52 27 N	21 41 53 E	60 52.450 N	21 41.883 E	16	T	crossroads	078LAIT	132	285
616	Lamminkoski	62 05 27 N	23 02 41 E	62 05.450 N	23 02.683 E	136	T	T-junction	616LASKI	160	347
704	Lansi-Aure	61 58 45 N	23 21 31 E	61 58.750 N	23 21.517 E	171	T	crossroads	704LAURE	143	351
705	Lansi-Teisko	61 44 59 N	23 41 57 E	61 44.983 N	23 41.950 E	110	T	crossroads	705LTEIS	114	356
119	Lapinjarvi	60 37 07 N	26 11 57 E	60 37.117 N	26 11.950 E	22	T	crossroads	119LAPIN	114	104
302	Lapinlahti	63 23 58 N	27 28 44 E	63 23.967 N	27 28.733 E	100	AT	airfield	302LAPIN	343	37
126	Lapinneva	61 58 38 N	22 56 33 E	61 58.633 N	22 56.550 E	138	T	crossroads	126LAPIN	151	343
904	Lappeenranta	61 02 21 N	28 07 05 E	61 02.350 N	28 07.083 E	106	AT	VOR/DME VILMAS	904EFLP	219	87
116	Lappi	61 04 15 N	21 50 34 E	61 04.250 N	21 50.567 E	48	T	island	116LAPPI	128	295
193	Launonen	60 44 12 N	24 33 58 E	60 44.200 N	24 33.967 E	120	T	crossroads	193LANEN	24	99
5	Lautaporras	60 54 33 N	23 51 49 E	60 54.550 N	23 51.817 E	107	T	crossroads	005LAUTA	23	331
45	Lauttakyla	61 10 10 N	22 40 32 E	61 10.167 N	22 40.533 E	81	T	crossroads	045LAUTT	91	309
180	Lavia	61 35 48 N	22 35 08 E	61 35.800 N	22 35.133 E	125	T	crossroads	180LAVIA	126	327
181	Lehtimaki	62 49 04 N	23 56 36 E	62 49.067 N	23 56.600 E	96	T	crossroads	181LEHTI	231	5
325	Leivonmaki	61 53 51 N	26 11 16 E	61 53.850 N	26 11.267 E	134	AT	unofficial airfield	325LVNMK	169	47
94	Lemi	61 03 42 N	27 48 15 E	61 03.700 N	27 48.250 E	103	T	crossroads	094LEMI	202	86
336	Leppavirta	62 29 42 N	27 45 20 E	62 29.700 N	27 45.333 E	102	T	crossroads	336LEPPA	274	51
603	Liedenpohja	62 22 23 N	23 38 44 E	62 22.383 N	23 38.733 E	98	T	bridge	603LIHJA	183	360
313	Liekka-Nurmes	63 30 43 N	29 37 45 E	63 30.717 N	29 37.750 E	114	AT	airfield	313LIEKS	420	48
9	Lietsa	60 49 41 N	24 01 00 E	60 49.683 N	24 01.000 E	113	T	crossroads	009LIETS	11	337
327	Lievestuore	62 15 02 N	26 10 21 E	62 15.033 N	26 10.350 E	132	T	crossroads	327LIEVE	200	40
144	Lievikoski	61 21 05 N	22 28 34 E	61 21.083 N	22 28.567 E	47	T	crossroads	144LISKI	111	316
340	Liperi	62 31 49 N	29 23 19 E	62 31.817 N	29 23.317 E	116	T	crossroads	340LIPER	342	60
60	Lohja	60 12 15 N	24 00 06 E	60 12.250 N	24 00.100 E	99	T	tower	060LOHJA	60	194
27	Loimaa	60 50 29 N	23 04 12 E	60 50.483 N	23 04.200 E	99	T	silos	027LOIMA	58	289
706	Luhalahti	61 46 34 N	23 15 36 E	61 46.567 N	23 15.600 E	92	T	T-junction	706LUHAL	124	346
61	Lusi	61 18 01 N	26 04 41 E	61 18.017 N	26 04.683 E	125	T	T-junction	061LUSI	122	66
75	Luumaki	60 55 16 N	27 33 34 E	60 55.267 N	27 33.567 E	98	T	stadion	075LUAKI	188	90
154	Mallusjarvi	60 44 15 N	25 39 36 E	60 44.250 N	25 39.600 E	50	T	bridge	154MARVI	84	98
973	Malmi	60 15 14 N	25 02 39 E	60 15.233 N	25 02.650 E	18	AT	airfield	973EFHF	74	144
131	Mankala	60 54 49 N	26 12 51 E	60 54.817 N	26 12.850 E	106	T	railway bridge	131MANKA	115	87
128	Mansoniemi	61 51 01 N	22 55 58 E	61 51.017 N	22 55.967 E	138	T	bridge	128MANSO	138	341
960	Mantsala	60 34 21 N	25 30 32 E	60 34.350 N	25 30.533 E	41	AT	airfield	960EFMN	78	111
183	Mantta	62 01 35 N	24 37 42 E	62 01.583 N	24 37.700 E	144	T	Paper mill	183MANTT	145	18
322	Mantyarju	61 25 47 N	26 52 46 E	61 25.783 N	26 52.767 E	82	T	bridge	322MANTY	167	69
612	Mayry	62 46 09 N	23 31 38 E	62 46.150 N	23 31.633 E	84	T	crossroads	612MAYRY	227	360
112	Menkijarvi	62 56 48 N	23 31 08 E	62 56.800 N	23 31.133 E	101	DSFT	airfield	112MENKI	247	0
308	Mikkeli	61 41 11 N	27 12 00 E	61 41.183 N	27 12.000 E	100	AT	airfield	308MKKE	196	64

Number	Name	Latitude ° , ' , ''	Longitude ° , ' , ''	Latitude ° , ' , ''	Longitude ° , ' , ''	Elevation METERS	Codes *	Comment	ID	Distance Km	Bearing
605	Moksy	63 02 01 N	24 10 01 E	63 02.017 N	24 10.017 E	163	T	transformer	605MOKSY	255	8
24	Mommila	60 50 39 N	25 01 43 E	60 50.650 N	25 01.717 E	88	T	bridge	024MOMMI	51	84
185	Multia	62 23 58 N	24 47 26 E	62 23.967 N	24 47.433 E	141	T	bridge	185MULTI	188	18
707	Murole	61 49 17 N	23 57 03 E	61 49.283 N	23 57.050 E	100	T	T-junction	707MUROL	120	3
198	Mynamaki	60 41 05 N	21 59 27 E	60 41.083 N	21 59.450 E	12	T	crossroads	198MYNKI	116	275
81	Naarajarvi	62 15 58 N	26 59 54 E	62 15.967 N	26 59.900 E	119	AT	airfield	081NAARA	228	48
51	Nastola	60 57 19 N	25 56 05 E	60 57.317 N	25 56.083 E	92	T	bridge	051NASTO	101	83
122	Niinisalo	61 51 26 N	22 29 31 E	61 51.433 N	22 29.517 E	135	T	crossroads	122NIINI	151	333
708	Niskos	62 10 05 N	23 17 25 E	62 10.083 N	23 17.417 E	145	T	bridge	708NISKO	164	352
30	Nummela	60 20 02 N	24 17 47 E	60 20.033 N	24 17.783 E	112	DSFT	airfield	030NUMME	46	175
140	Nummensyrja	60 37 47 N	24 21 02 E	60 37.783 N	24 21.033 E	143	T	sand pit	140NURJA	18	142
619	Nummijarvi	62 18 25 N	22 26 45 E	62 18.417 N	22 26.750 E	163	T	T-junction	619NURVI	195	341
38	Oripaa	60 52 22 N	22 44 38 E	60 52.367 N	22 44.633 E	101	AT	AF	038ORIPA	76	289
158	Ortenoja	60 48 45 N	22 38 15 E	60 48.750 N	22 38.250 E	70	T	crossroads	158OROJA	81	284
513	Otanmaki	64 06 50 N	27 05 43 E	64 06.833 N	27 05.717 E	184	T	bridge	513OTANM	405	28
915	Oulu	64 55 54 N	25 21 33 E	64 55.900 N	25 21.550 E	14	AT	VOR/DME OULU	915EFOU	470	15
339	Outokumpu	62 43 52 N	29 00 33 E	62 43.867 N	29 00.550 E	113	T	tower	339OUTOK	339	55
44	Padasjoki	61 20 37 N	25 14 52 E	61 20.617 N	25 14.867 E	127	T	crossroads	044PADAS	90	49
204	Paimio	60 25 40 N	22 43 25 E	60 25.667 N	22 43.417 E	52	T	Highway bridge	204PAIMO	84	253
67	Parkano	61 59 41 N	23 00 46 E	61 59.683 N	23 00.767 E	137	T	crossroads	067PARKA	151	345
709	Parkkuu	61 49 08 N	23 41 50 E	61 49.133 N	23 41.833 E	98	T	T-junction	709PARKK	122	357
74	Pellosniemi	61 27 11 N	27 15 52 E	61 27.183 N	27 15.867 E	98	T	T-junction	074PELLO	187	71
618	Peraseinajoki	62 34 04 N	23 03 17 E	62 34.067 N	23 03.283 E	95	T	crossroads	618PEOKI	211	353
186	Perho	63 12 54 N	24 24 57 E	63 12.900 N	24 24.950 E	122	T	crossroads	186PERHO	275	11
133	Pernio	60 12 19 N	23 06 42 E	60 12.317 N	23 06.700 E	9	T	crossroads	133PERNI	81	231
146	Petajavesi	62 14 59 N	25 10 55 E	62 14.983 N	25 10.917 E	108	T	bridge	146PETAJ	177	26
332	Pieksamaki	62 17 12 N	27 05 58 E	62 17.200 N	27 05.967 E	114	T	crossroads	332PIEKS	233	49
57	Piikajarvi	61 14 44 N	22 11 35 E	61 14.733 N	22 11.583 E	45	AT	airfield	057PIIKA	118	307
160	Pirttijarvi	61 44 27 N	22 42 10 E	61 44.450 N	22 42.167 E	114	T	crossroads	160PIRVI	134	334
96	Pitkakoski	60 40 24 N	27 35 05 E	60 40.400 N	27 35.083 E	35	T	bridge	096PITKA	189	98
43	Pohja	61 28 58 N	24 42 19 E	61 28.967 N	24 42.317 E	128	T	crossroads	043POHJA	88	28
710	Poikelus	61 47 30 N	23 37 42 E	61 47.500 N	23 37.700 E	120	T	T-junction	710POIKE	120	355
343	Polvijarvi	62 50 58 N	29 20 26 E	62 50.967 N	29 20.433 E	116	T	crossroads	343POLVI	361	55
906	Pori	61 27 53 N	21 47 45 E	61 27.883 N	21 47.750 E	13	AT	VOR/DME PREVIK	906EFPO	148	311
2	Porras	60 45 08 N	23 54 35 E	60 45.133 N	23 54.583 E	113	T	T-junction	002PORRA	11	283
132	Pottikyla	60 55 27 N	28 01 38 E	60 55.450 N	28 01.633 E	56	T	railway bridge	132POTTI	213	90
203	Prunkila	60 34 11 N	22 47 02 E	60 34.183 N	22 47.033 E	49	T	Bridge	203PRULA	75	263
501	Pudasjarvi	65 24 08 N	26 56 49 E	65 24.133 N	26 56.817 E	121	AT	airfield	501PUDAS	537	22
515	Pulkkila	64 15 57 N	25 52 13 E	64 15.950 N	25 52.217 E	91	T	crossroads	515PULKK	402	20
306	Punkaharju	61 43 44 N	29 23 37 E	61 43.733 N	29 23.617 E	77	AT	airfield	306PUNKA	303	74
36	Punkalaidun	61 06 44 N	23 06 22 E	61 06.733 N	23 06.367 E	95	T	T-junction	036PUNKA	68	315

<i>Number</i>	<i>Name</i>	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Elevation</i> <i>METERS</i>	<i>Codes</i> *	<i>Comment</i>	<i>ID</i>	<i>Distance</i> <i>Km</i>	<i>Bearing</i>
50	Pusula	60 28 23 N	23 58 57 E	60 28.383 N	23 58.950 E	103	T	crossroads	050PUSUL	31	201
88	Putula	61 05 57 N	25 13 11 E	61 05.950 N	25 13.183 E	118	T	crossroads	088PUTUL	72	63
514	Pyhanta	64 05 54 N	26 20 32 E	64 05.900 N	26 20.533 E	126	T	crossroads	514PYHAN	390	24
310	Pyhasalmi	63 43 45 N	25 55 55 E	63 43.750 N	25 55.917 E	161	AT	airfield	310PYHAS	345	22
187	Pylkonmaki	62 40 24 N	24 48 12 E	62 40.400 N	24 48.200 E	128	T	T-junction	187PYLKO	218	17
962	Raahе	64 41 17 N	24 41 45 E	64 41.283 N	24 41.750 E	36	AT	airfield	962EFRF	440	11
124	Raivala	61 56 20 N	22 46 46 E	61 56.333 N	22 46.767 E	141	T	crossroads	124RAIVA	151	340
311	Rantasalmi	62 03 56 N	28 21 24 E	62 03.933 N	28 21.400 E	89	AT	airfield	311RANTA	269	63
516	Rantsila	64 30 26 N	25 39 14 E	64 30.433 N	25 39.233 E	64	T	crossroads	516RANTS	426	17
502	Ranua	65 58 23 N	26 21 55 E	65 58.383 N	26 21.917 E	165	AT	airfield	502RANUA	592	17
188	Rautajarvi	61 24 35 N	24 43 02 E	61 24.583 N	24 43.033 E	125	T	T-junction	188RAUTA	81	31
335	Rautalampi	62 37 44 N	26 47 44 E	62 37.733 N	26 47.733 E	112	T	crossroads	335RAUTA	253	40
301	Rautavaara	63 25 27 N	28 07 27 E	63 25.450 N	28 07.450 E	145	AT	airfield	301RAUTA	364	41
1	Rayskala	60 44 33 N	24 07 05 E	60 44.550 N	24 07.083 E	124	HDTs	airfield	001RAYSK		
998	<i>Rayskala_F08</i>	60 44 29 N	24 05 31 E	60 44.483 N	24 05.517 E	124	DF	airfield	998R_F08	1.4	273
999	<i>Rayskala_F12</i>	60 45 03 N	24 05 52 E	60 45.050 N	24 05.867 E	124	DF	airfield	999R_F12	1.4	318
617	Reisjarvi	63 36 13 N	24 57 00 E	63 36.217 N	24 57.000 E	113	T	bridge	617REVI	321	15
4	Renko	60 54 06 N	24 17 26 E	60 54.100 N	24 17.433 E	116	T	crossroads	004RENKO	20	35
14	Riihimaki	60 46 16 N	24 47 05 E	60 46.267 N	24 47.083 E	105	T	bridge	014RIIHI	36	92
80	Riisikkala	61 02 29 N	23 45 59 E	61 02.483 N	23 45.983 E	103	T	tower	080RIISI	38	338
53	Riste	61 15 52 N	22 24 52 E	61 15.867 N	22 24.867 E	66	T	silos	053RISTE	109	311
916	Rovaniemi	66 33 45 N	25 49 14 E	66 33.750 N	25 49.233 E	197	AT	VOR/DME ROVANI	916EFRO	653	14
125	Rukoneva	61 57 21 N	22 51 08 E	61 57.350 N	22 51.133 E	138	T	crossroads	125RUKON	151	341
161	Ruotsinkyla	60 36 50 N	26 27 51 E	60 36.833 N	26 27.850 E	20	T	crossroads	161RUYLA	129	103
166	Ruuhasjarvi	61 08 52 N	26 31 02 E	61 08.867 N	26 31.033 E	82	T	crossroads	166RURVI	137	77
201	Saksala	60 43 02 N	22 20 35 E	60 43.033 N	22 20.583 E	74	T	crossroads	201SAKLA	97	277
35	Salo	60 23 37 N	23 07 53 E	60 23.617 N	23 07.883 E	84	T	crossroads	035SALO	66	242
87	Saloinen	60 57 40 N	24 52 19 E	60 57.667 N	24 52.317 E	116	T	crossroads	087SALOI	48	66
69	Saukkola	60 22 49 N	23 57 28 E	60 22.817 N	23 57.467 E	103	T	crossroads	069SAUKK	41	200
963	Savikko	60 31 12 N	24 49 54 E	60 31.200 N	24 49.900 E	71	AT	airfield	963EFNS	46	130
93	Savitaipale	61 11 58 N	27 41 11 E	61 11.967 N	27 41.183 E	105	T	church	093SAALE	199	81
908	Savonlinna	61 57 10 N	28 54 51 E	61 57.167 N	28 54.850 E	95	AT	VOR/DME LINNA	908EFSA	289	68
115	Seinajoki	62 41 37 N	22 49 55 E	62 41.617 N	22 49.917 E	91	AT	airfield	115SEINA	227	351
711	Seitseminen	61 56 59 N	23 22 18 E	61 56.983 N	23 22.300 E	171	T	yard	711SEITS	140	351
66	Selanpaa	61 03 51 N	26 47 45 E	61 03.850 N	26 47.750 E	127	AT	airfield	066SELAN	149	82
117	Siikainen	61 52 36 N	21 49 18 E	61 52.600 N	21 49.300 E	51	T	crossroads	117SIIKA	176	324
712	Siikakangas	61 50 38 N	24 11 57 E	61 50.633 N	24 11.950 E	169	T	old airfield	712SIIKA	123	9
606	Simpsio	62 57 21 N	22 57 09 E	62 57.350 N	22 57.150 E	123	T	mast	606SISIO	254	354
95	Sippola	60 41 32 N	27 02 48 E	60 41.533 N	27 02.800 E	72	T	TV-mast	095SIPPO	159	98
713	Sisatonjarvi	61 50 10 N	23 20 26 E	61 50.167 N	23 20.433 E	120	T	T-junction	713SISN	128	349
189	Soini	62 52 23 N	24 12 23 E	62 52.383 N	24 12.383 E	108	T	crossroads	189SOINI	237	9

<i>Number</i>	<i>Name</i>	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Elevation</i> <i>METERS</i>	<i>Codes</i> [*]	<i>Comment</i>	<i>ID</i>	<i>Distance</i> <i>Km</i>	<i>Bearing</i>
20	Somerniemi	60 34 14 N	23 43 53 E	60 34.233 N	23 43.883 E	107	T	crossroads	020SOMER	28	235
12	Somero	60 37 20 N	23 31 13 E	60 37.333 N	23 31.217 E	96	T	bridge	012SOMER	35	255
348	Sonkajarvi	63 40 22 N	27 31 32 E	63 40.367 N	27 31.533 E	144	T	crossroads	348SONKA	371	34
46	Stromma	60 11 16 N	22 52 05 E	60 11.267 N	22 52.083 E	10	T	bridge	046STROM	92	236
511	Sukeva	63 52 12 N	27 26 39 E	63 52.200 N	27 26.650 E	157	T	crossroads	511SUKEV	388	32
114	Sulkaharju	63 23 52 N	24 01 50 E	63 23.867 N	24 01.833 E	122	AT	airfield	114SULKA	295	7
173	Sulkava	60 44 58 N	25 12 28 E	60 44.967 N	25 12.467 E	82	T	crossroads	173SUAVA	59	96
333	Sumiainen	62 39 28 N	26 02 39 E	62 39.467 N	26 02.650 E	125	T	crossroads	333SUMIA	236	32
611	Suni	62 47 02 N	24 00 45 E	62 47.033 N	24 00.750 E	155	T	bridge	611SUNI	227	6
59	Suodenniemi	61 33 07 N	22 45 47 E	61 33.117 N	22 45.783 E	72	T	bridge	059SUODE	116	329
97	Suomenniemi	61 19 34 N	27 27 02 E	61 19.567 N	27 27.033 E	105	T	crossroads	097SUOME	191	76
964	Suomussalmi	64 49 19 N	28 42 37 E	64 49.317 N	28 42.617 E	165	AT	airfield	964EFSU	510	33
83	Suonenjoki	62 37 54 N	27 06 18 E	62 37.900 N	27 06.300 E	109	T	crossroads	083SUONE	263	43
123	Sydanmaa	61 53 40 N	22 35 34 E	61 53.667 N	22 35.567 E	140	T	crossroads	123SYDAN	152	336
614	Sykarainen	63 37 03 N	24 24 33 E	63 37.050 N	24 24.550 E	117	T	T-junction	614SYNEN	320	10
31	Syrjantaka	61 06 19 N	24 51 31 E	61 06.317 N	24 51.517 E	122	T	crossroads	031SYRJA	57	52
321	Sysma	61 30 18 N	25 41 10 E	61 30.300 N	25 41.167 E	126	T	crossroads	321SYSMA	119	52
324	Tammijarvi	61 49 57 N	25 49 31 E	61 49.950 N	25 49.517 E	130	T	T-junction	324TAMMI	152	44
47	Tammisaari	59 58 58 N	23 25 47 E	59 58.967 N	23 25.783 E	54	T	T-junction	047TAMMI	93	212
56	<i>Teisko</i>	61 46 20 N	24 01 25 E	61 46.333 N	24 01.417 E	157	DSFT	airfield	056TEISK	115	5
194	Tervahauta	61 28 30 N	22 33 28 E	61 28.500 N	22 33.467 E	115	T	crossroads	194TERVA	117	322
18	Tervakoski	60 49 25 N	24 40 02 E	60 49.417 N	24 40.033 E	118	T	crossroads	018TERVA	31	80
118	Teuva	62 29 27 N	21 44 47 E	62 29.450 N	21 44.783 E	64	T	crossroads	118TEUVA	231	336
615	Toholampi	63 46 18 N	24 14 52 E	63 46.300 N	24 14.867 E	94	T	crossroads	615TOMPI	337	9
34	Toija	60 16 04 N	23 25 04 E	60 16.067 N	23 25.067 E	84	T	T-junction	034TOIJA	65	224
3	Topeno	60 45 42 N	24 16 55 E	60 45.700 N	24 16.917 E	117	T	T-junction	003TOPEN	9.2	84
965	Torbacka	60 04 45 N	24 10 20 E	60 04.750 N	24 10.333 E	5	AT	airfield	965EFTO	74	185
195	Toysa	62 37 39 N	23 48 45 E	62 37.650 N	23 48.750 E	111	T	T-junction	195TOYSA	210	3
905	Tre-Pirkkala	61 24 36 N	23 34 40 E	61 24.600 N	23 34.667 E	119	AT	VOR/DME PIRKKA	905EFTP	80	346
72	Tuohikotti	61 05 22 N	27 03 41 E	61 05.367 N	27 03.683 E	112	T	crossroads	072TUOHI	164	83
13	Turenki	60 54 58 N	24 38 56 E	60 54.967 N	24 38.933 E	117	T	silos	013TUREN	35	63
902	Turku	60 30 55 N	22 15 24 E	60 30.917 N	22 15.400 E	49	AT	VOR/DME RUSKO	902EFTU	105	264
41	Tuuliharja	60 49 36 N	25 31 38 E	60 49.600 N	25 31.633 E	101	T	crossroads	041TUULI	77	90
338	Tuusniemi	62 48 32 N	28 29 40 E	62 48.533 N	28 29.667 E	106	T	crossroads	338TUUSN	325	51
182	Tyrvaa	61 19 44 N	22 50 46 E	61 19.733 N	22 50.767 E	59	T	hydropower plant	182TYVAA	95	322
184	Ummeljoki	60 45 26 N	26 44 21 E	60 45.433 N	26 44.350 E	41	AT	unofficial airfield	184UMOKI	142	96
121	Urajarvi	61 08 14 N	25 47 35 E	61 08.233 N	25 47.583 E	115	T	school bldg	121URAJA	101	71
23	Urjala	61 04 53 N	23 32 07 E	61 04.883 N	23 32.117 E	102	T	crossroads	023URJAL	49	328
517	Utajarvi	64 45 38 N	26 25 06 E	64 45.633 N	26 25.100 E	76	T	T-junction	517UTANJ	462	21
903	Utti	60 53 50 N	26 55 46 E	60 53.833 N	26 55.767 E	103	AT	VOR/DME UTTI	903EFUT	153	90
196	Uusikyla	63 02 01 N	24 07 41 E	63 02.017 N	24 07.683 E	110	T	T-junction	196UUSIK	255	8

<i>Number</i>	<i>Name</i>	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Latitude</i> ° , ' , ''	<i>Longitude</i> ° , ' , ''	<i>Elevation</i> <i>METERS</i>	<i>Codes</i> *	<i>Comment</i>	<i>ID</i>	<i>Distance</i> <i>Km</i>	<i>Bearing</i>
120	Vaaksy	61 10 34 N	25 32 12 E	61 10.567 N	25 32.200 E	92	T	channel	120VAAKS	90	65
504	Vaala	64 30 07 N	26 45 36 E	64 30.117 N	26 45.600 E	135	AT	airfield	504VAALA	439	24
912	Vaasa	63 02 29 N	21 45 54 E	63 02.483 N	21 45.900 E	6	AT	VOR/DME VAASA	912EFVA	284	343
714	Vaha Mustajarvi	62 05 10 N	23 24 11 E	62 05.167 N	23 24.183 E	160	T	bridge	714VMUST	154	354
349	Valtimo	63 41 19 N	28 47 52 E	63 41.317 N	28 47.867 E	131	T	crossroads	349VALTI	407	42
103	Vampula	61 02 23 N	22 35 30 E	61 02.383 N	22 35.500 E	90	AT	airfield	103VAMPU	89	300
135	Vanttila	61 08 33 N	22 57 02 E	61 08.550 N	22 57.033 E	78	T	crossroads	135VANNT	77	313
309	Varkaus	62 10 16 N	27 52 07 E	62 10.267 N	27 52.117 E	87	AT	airfield	309VARKA	255	57
138	Velaatta	61 44 51 N	23 55 31 E	61 44.850 N	23 55.517 E	112	T	bridge	138VELAA	112	2
197	Venesjarvi	61 49 15 N	22 11 56 E	61 49.250 N	22 11.933 E	126	T	T-junction	197VENES	158	328
42	Ventela	60 16 58 N	24 06 59 E	60 16.967 N	24 06.983 E	77	T	crossroads	042VENTE	51	188
48	Vesivehmaa	61 08 37 N	25 41 23 E	61 08.617 N	25 41.383 E	153	DTS	airfield	048VESIV	96	69
996	Vesivehmaa_F07	61 08 33 N	25 41 00 E	61 08.550 N	25 41.000 E	153	DF	Finish point	996V_F07	96	69
997	Vesivehmaa_F25	61 08 45 N	25 42 05 E	61 08.750 N	25 42.083 E	153	DF	Finish point	997V_F25	97	69
607	Veteli	63 29 31 N	23 45 14 E	63 29.517 N	23 45.233 E	67	T	crossroads	607VEELI	306	4
512	Vierema	63 52 37 N	26 48 34 E	63 52.617 N	26 48.567 E	145	T	highway	512VIERE	375	28
90	Vierumaki	61 06 47 N	25 55 26 E	61 06.783 N	25 55.433 E	146	T	bridge	090VIERU	106	74
28	Vihti	60 22 49 N	24 15 31 E	60 22.817 N	24 15.517 E	103	T	crossroads	028VIHTI	41	177
342	Viitaniemi	63 08 07 N	28 29 03 E	63 08.117 N	28 29.050 E	113	T	crossroads	342VIITA	350	46
307	Viitasaari	63 07 21 N	25 48 58 E	63 07.350 N	25 48.967 E	110	AT	airfield	307VIITA	279	25
715	Vilppula	62 00 45 N	24 29 09 E	62 00.750 N	24 29.150 E	99	T	bridge	715VILPP	143	15
73	Virrat	62 15 02 N	23 47 01 E	62 15.033 N	23 47.017 E	114	T	crossroads	073VIRRA	169	2
331	Virtasalmi	62 07 52 N	27 26 43 E	62 07.867 N	27 26.717 E	100	T	bridge	331VIRTA	235	55
199	Visuvesi	62 07 04 N	23 55 32 E	62 07.067 N	23 55.533 E	140	T	Canal	199VISUV	153	4
8	Vojakkala	60 46 53 N	24 09 46 E	60 46.883 N	24 09.767 E	117	T	crossroads	008VOJAK	5.0	37
98	Wredeby	60 39 49 N	26 44 45 E	60 39.817 N	26 44.750 E	25	AT	airfield	098WREDE	143	100
190	Ylane	60 53 12 N	22 24 06 E	60 53.200 N	22 24.100 E	49	T	crossroads	190YLANE	94	288
200	Ylistaro	62 56 32 N	22 30 53 E	62 56.533 N	22 30.883 E	35	T	bridge	200YLIST	259	349
507	Ylivieska	64 03 17 N	24 43 31 E	64 03.283 N	24 43.517 E	77	AT	airfield	507YLIVI	370	12
79	Ypaja	60 46 20 N	23 20 43 E	60 46.333 N	23 20.717 E	100	T	crossroads	079YPAJA	42	282

Codes*

- A: Airport
- D: Glider Airfield
- F: Finish Point
- H: Home airport
- S: Start Point
- T: Turnpoint